



### Mounting the Device



- Insert mounting tabs into the body of the device
- Use screws to firmly fix device to a flat surface
- Discreetly mounted under dash



- DO NOT cable tie to looms/harnesses
- DO NOT mount next to sources of electrical noise (engine management system, coil, leads, distributor etc.)

### GPS Antenna



- Clear view of the sky in all directions
- Mounted on a horizontal metal surface
- Mounted to a metal surface minimum 10cm x 10cm
- Discreetly mounted under dash or rear parcel shelf



- DO NOT mount to plastic
- DO NOT mount next to sources of electrical noise (engine management system, coil, leads, distributor etc.)
- DO NOT mount near GSM or other antennas allow 50cm clearance

### GSM Antenna



- Mount away from any solid metal
- Mount high up in dash to plastic
- Where possible mount discreetly



- DO NOT stick GSM antenna on metal surface
- DO NOT mount near GPS or other antennas allow 50cm clearance
- DO NOT mount next to sources of electrical noise (engine management system, coil, leads, distributor etc.)

## Power Harness I/O



Basic 3 Wire Connection	
Red	Battery 12-24 VDC (fused)
White	Ignition 12-24 VDC
Black	Ground

Contact IntelliTrac regarding additional wiring information (external inputs etc.)

## LED Indicators, regular operation

Indicators	Blinking Behavior	Status
GSM (Red)	0.6 second on/ 0.6 second off	Not Ready or Searching GSM signal
	<b>0.1 second on / 3 seconds off</b>	<b>Registered to network successfully</b>
GPS (Green)	Off	GPS off
	1 second on / 1 seconds off	GPS not fixed
	<b>Solid on</b>	<b>GPS fixed</b>



GSM/GPS Indicators

## BEFORE LEAVING VEHICLE

Confirm installation and activate device by calling IntelliTrac on

**03 8456 0681**

A service representative will confirm the device is operating correctly and calibrate  
Odometer/Hourmeter