


**Note: RFID used as per Customers Requirements**



This Side facing Up

RFID READER



RFID buzzer will sound when ignition is on  
To silence swipe valid RFID card

Note: Caution where mounting RFID  
Frequency may interfere with vehicle transponders

White from RFID reader connector  
to Green from ES810 connector

Green RFID Buzzer

White Ignition +12/24V

Red +12/24V

Black GND

## WIRING GUIDE

### Black Connector

- RED – 12-24V
- BLACK – Ground
- White – Ignition
- Green – White wire of RFID Reader

### White Connector

- GREEN – RED (RFID READER CONNECTOR) - 5V
- PURPLE – BLACK (RFID READER CONNECTOR) – GND
- ORANGE – GREEN (RFID READER CONNECTOR) – TX->RX

### BEFORE LEAVING VEHICLE

Confirm installation by calling IntelliTrac on  
**03 9467 6188 (option 7 followed by option 1)**  
a service representative will confirm the device is  
operating correctly